
Cable name =UNIT_03++Container+-290W3-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:7	
			++ASC-369XT:10	
			++ASC-369XT:1	
			++ASC-369XT:4	

Cable name =UNIT_03++Container+-290W1-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:7	
			++ASC-369XT:10	
			++ASC-369XT:1	
			++ASC-369XT:4	

Cable name =UNIT_03++Container+-290W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:7	
			++ASC-369XT:10	
			++ASC-369XT:1	
			++ASC-369XT:4	


previous page:
&EPA++ASC/2

next page:
2

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++Container+-291W1-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:8	
			++ASC-369XT:11	
			++ASC-369XT:2	
			++ASC-369XT:5	

Cable name =UNIT_03++Container+-291W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:8	
			++ASC-369XT:11	
			++ASC-369XT:2	
			++ASC-369XT:5	

Cable name =UNIT_03++Container+-292W1-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			


L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:8	
			++ASC-369XT:11	
			++ASC-369XT:2	
			++ASC-369XT:5	

previous page: 1
next page: 3

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++Container+-292W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:9	
			++ASC-369XT:12	
			++ASC-369XT:3	
			++ASC-369XT:6	

Cable name =UNIT_03++Container+-292W3-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:9	
			++ASC-369XT:12	
			++ASC-369XT:3	
			++ASC-369XT:6	

Cable name =UNIT_03++Container+-293W1-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-570XT:1			
	-570XT:2			
	-570XT:3			
	-570XT:4			


L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-369XT:9	
			++ASC-369XT:12	
			++ASC-369XT:3	
			++ASC-369XT:6	

previous page: 2
next page: 4

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++Container+-293W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]	L2 [mm]	wire end handling	Function text target	Target	Mounting location:
	-570XT:1							++ASC-369XT:9	
	-570XT:2							++ASC-369XT:12	
	-570XT:3							++ASC-369XT:3	
	-570XT:4							++ASC-369XT:6	

Cable name =UNIT_03++Container+-293W3-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]	L2 [mm]	wire end handling	Function text target	Target	Mounting location:
	-570XT:1							++ASC-369XT:8	
	-570XT:2							++ASC-369XT:11	
	-570XT:3							++ASC-369XT:2	
	-570XT:4							++ASC-369XT:5	

Cable name =UNIT_03++Container+-290W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number



Mounting location:	Source	Function text source	wire end handling	L1 [mm]	L2 [mm]	wire end handling	Function text target	Target	Mounting location:
	-XE:1							++ASC-687XT1:1	
	-XE:N							++ASC-687XT1:N	
	-XE:PE							++ASC-687XT1:PE	

previous page: 3
next page: 5

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++Container+-290W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:2	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-290W3-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:3	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-291W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:4	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-291W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			


L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:5	
			++ASC-687XT1:N	

previous page: 4
next page: 6

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++Container+-291W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-292W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:6	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-292W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:7	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-292W3-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			


L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:8	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

previous page: 5
next page: 7

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++Container+-293W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:9	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-293W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:10	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-293W3-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-XE:1			
	-XE:N			
	-XE:PE			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-687XT1:11	
			++ASC-687XT1:N	
			++ASC-687XT1:PE	

Cable name =UNIT_03++Container+-290W1-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN



Mounting location:	Source	Function text source	wire end handling	L1 [mm]


L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-611A1:X1:1-16	

previous page: 6
next page: 8

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++Container+-290W2-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors


Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN



Mounting location:	Source	Function text source	wire end handling	L1 [mm]	L2 [mm]	wire end handling	Function text target	Target	Mounting location:
								++ASC-611A1:X2:1-16	

Cable name =UNIT_03++Container+-290W3-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors


Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN



Mounting location:	Source	Function text source	wire end handling	L1 [mm]	L2 [mm]	wire end handling	Function text target	Target	Mounting location:
								++ASC-611A1:X3:1-16	

Cable name =UNIT_03++Container+-291W1-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors


Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN



Mounting location:	Source	Function text source	wire end handling	L1 [mm]	L2 [mm]	wire end handling	Function text target	Target	Mounting location:
								++ASC-611A1:X4:1-16	

Cable name =UNIT_03++Container+-291W2-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors


Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN



Mounting location:	Source	Function text source	wire end handling	L1 [mm]	L2 [mm]	wire end handling	Function text target	Target	Mounting location:
								++ASC-611A1:X5:1-16	

Cable name =UNIT_03++Container+-292W1-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN




Mounting location:	Source	Function text source	wire end handling	L1 [mm]	L2 [mm]	wire end handling	Function text target	Target	Mounting location:
								++ASC-611A1:X6:1-16	

previous page: 7
next page: 9

FRQ_Kabelplan_04_gro8_de_en

Cable name =UNIT_03++Container+-292W2-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-611A1:X7:1-16	

Cable name =UNIT_03++Container+-292W3-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-611A1:X8:1-16	

Cable name =UNIT_03++Container+-293W1-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-611A1:X9:1-16	

Cable name =UNIT_03++Container+-293W2-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-611A1:X2:1-16	

Cable name =UNIT_03++Container+-293W3-3
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 7,5 GN
Order number PATCH-C6 7,5 GN



Mounting location:	Source	Function text source	wire end handling	L1 [mm]


L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			++ASC-611A1:X3:1-16	

Editor	Freqcon_DG			Statron	FREQCON	CABEL LIST	20241105_V1.2	= UNIT_03	Battery Container 2
Date	05.11.2024							& EMB	Cable list
Proved by				Shell Crosswind BESS FQ 1MW 5MWh Offshore			10354_23A2007	++ Container	page: 9
Date								+	total: 498

FRQ_Kabelplan_04_gro8_de_en

Cable name =UNIT_03++ASC+-680W1
Cable type F-CY-JZ 10G0,75 mm²
Free conductors

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-X5.1:2	gas concentration BAT 1-4		
	-X5.1:3	=		
	-X5.1:5	=		
	-X5.1:6	=		
	-X5.1:7	=		
	-X5.1:8	=		
	-X5.1:9	=		
	-X5.1:10	=		
	-X5.1:PE	=		

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
		gas concentration	++Container-680U1-X1:2	
		=	++Container-680U1-X1:4	
		=	++Container-680U1-X2:1	
		=	++Container-680U1-X2:2	
		=	++Container-680U1-X2:4	
		=	++Container-680U1-X2:5	
		=	++Container-680U1-X2:7	
		=	++Container-680U1-X2:8	
		=	++Container-680U1-X1:5	

Cable name =UNIT_03++ASC+-680W2
Cable type F-CY-JZ 10G0,75 mm²
Free conductors

Cable parts
Order number



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-X5.2:2	gas concentration BAT 5-8		
	-X5.2:3	=		
	-X5.2:5	=		
	-X5.2:6	=		
	-X5.2:7	=		
	-X5.2:8	=		
	-X5.2:9	=		
	-X5.2:10	=		
	-X5.2:PE	=		

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
		gas concentration	++Container-680U2-X1:2	
		=	++Container-680U2-X1:4	
		=	++Container-680U2-X2:1	
		=	++Container-680U2-X2:2	
		=	++Container-680U2-X2:4	
		=	++Container-680U2-X2:5	
		=	++Container-680U2-X2:7	
		=	++Container-680U2-X2:8	
		=	++Container-680U2-X1:5	

FRQ_Kabelplan_04_gro8_de_en


previous page:
++Container/9

next page:
2

0	1	2	3	4	5	6	7	8	9

Cable name =UNIT_03++ASC+-680W3
Cable type F-CY-JZ 10G0,75 mm²
Free conductors 0

Cable parts
Order number




Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-X5.3:2	gas concentration BAT 9-11		
	-X5.3:3	=		
	-X5.3:5	=		
	-X5.3:6	=		
	-X5.3:7	=		
	-X5.3:8	=		
	-X5.3:9	=		
	-X5.3:10	=		
	-X5.3:PE	=		

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
		gas concentration	++Container-680U3-X1:2	
		=	++Container-680U3-X1:4	
		=	++Container-680U3-X2:1	
		=	++Container-680U3-X2:2	
		=	++Container-680U3-X2:4	
		=	++Container-680U3-X2:5	
		=	++Container-680U3-X2:7	
		=	++Container-680U3-X2:8	
		=	++Container-680U3-X1:5	

Cable name =UNIT_03++ASC+-290W1-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-290W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

previous page: 1
next page: 3

FRQ_Kabelplan_04_gro8_de_en

Cable name =UNIT_03++ASC+-290W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-290W3-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-291W1-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:


previous page: 2

next page: 4

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++ASC+-291W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-292W1-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-292W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]


L2 [mm]	wire end handling	Function text target	Target	Mounting location:

previous page: 3
next page: 5

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++ASC+-292W3-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-293W1-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-293W2-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560



Mounting location:	Source	Function text source	wire end handling	L1 [mm]


L2 [mm]	wire end handling	Function text target	Target	Mounting location:

previous page: 4
next page: 6

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++ASC+-293W3-2
Cable type F-CY-OZ 4x0,75 mm²
Free conductors 4

Cable parts HELU.16560
Order number 16560




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-290W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-290W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091



Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

previous page: 5
next page: 7

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++ASC+-290W3-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-291W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-291W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-292W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091



Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:


previous page: 6

next page: 8

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++ASC+-292W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-292W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-292W3-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-293W1-1
Cable type JZ-500 3G1,5 mm²
Free conductors 3

Cable parts HELU.10091
Order number 10091



Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

previous page: 7
next page: 9

FRQ_Kabelplan_04_groß_de_en

Cable name =UNIT_03++ASC+-293W2-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-293W3-1
Cable type JZ-500 3G1,5 mm²
Free conductors

Cable parts HELU.10091
Order number 10091




Mounting location:	Source	Function text source	wire end handling	L1 [mm]

L2 [mm]	wire end handling	Function text target	Target	Mounting location:

Cable name =UNIT_03++ASC+-613W1
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 05 GN
Order number PATCH-C6 05 GN



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-613T1:7			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			-613U1:OUT	

Cable name =UNIT_03++ASC+-613W2
Cable type Patch cable Cat.6 4x2x0,25 mm²
Free conductors

Cable parts REI.PATCH-C6 05 GN
Order number PATCH-C6 05 GN



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
	-613U1:IN			


L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			-613U2:8	

Editor	Freqcon_DG			Statron	FREQCON	CABEL LIST	20241105_V1.2	= UNIT_03	Battery Container 2	
Date	05.11.2024							& EMB	Cable list	
Proved by				Shell Crosswind BESS FQ 1MW 5MWh Offshore			10354_23A2007	++ ASC	auxillary cabinet	page: 9
Date								+		total: 498

FRQ_Kabelplan_04_gro8_de_en

Cable name =UNIT_03++ASC+-113W8
Cable type S/FTP 4x2xAWG 23/1 PVC/PVC 4x2x23 AWG
Free conductors

Cable parts
Order number



Mounting location:	Source	Function text source	wire end handling	L1 [mm]
Control cabinet 1	=UNIT_01++CT+CTRL_1.3-113U4:8			
Control cabinet 1	=UNIT_01++CT+CTRL_1.3-113U4:4			
Control cabinet 1	=UNIT_01++CT+CTRL_1.3-113U4:2			
Control cabinet 1	=UNIT_01++CT+CTRL_1.3-113U4:6			
Control cabinet 1	=UNIT_01++CT+CTRL_1.3-113U4:7			
Control cabinet 1	=UNIT_01++CT+CTRL_1.3-113U4:5			
Control cabinet 1	=UNIT_01++CT+CTRL_1.3-113U4:1			
Control cabinet 1	=UNIT_01++CT+CTRL_1.3-113U4:3			

L2 [mm]	wire end handling	Function text target	Target	Mounting location:
			-613U2:8	
			-613U2:4	
			-613U2:2	
			-613U2:6	
			-613U2:7	
			-613U2:5	
			-613U2:1	
			-613U2:3	

FRQ_Kabelplan_04_gro8_de_en

previous page: 9
next page: &EMZ/1000